

Installation Procedure Cherry ST-1044 USB Reader and Cherry G83-6744 keyboard.

Important!


Do not connect the Smartcard reader before installing the software.

To install the software;

Insert the "Smartboard G83-6744 / SmartTerminal ST_1044U" CD.

A new window will open:

(If the CD-ROM does not start automatically, double-click the CD-ROM drive in windows explorer and then the Start.exe file)



Click "Start Software Installation"

Choose your Setup Language.

Follow the installation wizard, accept the License Agreement, click next.



Click next.

Select English and click next.

Click Finish.

Restart your pc.

If you have any problems installing the cardreader you can always call our helpdesk at

0902/520.20

